

Please keep this important information!

IMPORTANT

The instructions manual is to be read before use and kept for further reference. In case you give the product to another user, please provide him/her with this instructions manual, or a copy of it.

SAFETY INFORMATION

- Use only lamp oil or citronella oil.
- Never use gasoline, kerosene or other flammable fuels.
- Keep away from children and pets.
- **„Warning: In the case of small children, just a sip of lamp oil – or even sucking the wick – may lead to life-threatening lung damage.“**
- **„Warning: If lamp oil is swallowed, do not induce vomiting. Seek medical advice immediately or contact a poison information centre and show these warnings.“**
- **„Warning: Keep this oil lamp out of the reach of children both in use and when stored.“**
- Intended for OUTDOOR use only.
- Keep open flame away from flammable objects.
- Do not transport fire sphere it is lit or hot.

FILLING TORCH

- Remove the cap and unscrew the wick holder from the torch by pushing down and turning anti-clockwise.
- Fill the torch with lamp oil using a funnel to just over half way full.

- Do not fill near naked flame.
- Replace the wick and wick holder into the torch by pushing downwards and turning clockwise.
- Place the flame guard (snuffer cap) over wick holder when not in use.

LIGHTING THE TORCH

- Allow 5 - 7 minutes for the wick to fully saturate with oil before lighting.
- Remove flame guard (snuffer cap) and light the wick with a long match or lighter.
- If the torch burns with an excessiveley large flame or excessive smoke, extinguish the flame and allow to cool before adjusting the wick.

EXTINGUISHING THE TORCH

- Place the snuffer cap or other suitable fire resistant object completely over the flame guard until the flame has been extinguished.
- Do not touch the snuffer cap until it has had time to completely cool as it can become very hot when extinguishing flame.
- Wait for the torch completely cool down before moving, refilling with oil or putting away.

European Standard - EN14059:2002